


# Maytag GDE382 03 - FRONT VIEW



Maytag Residential Maytag GDE382 Dryer Parts Parts Diagram 03 - FRONT VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	<a href="#">62739</a>		Nut, Lock
2	<a href="#">204439</a>			Screw And Fstner Assembly
3	<a href="#">204445</a>			Screw And Fastener Assembly
4	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
6	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
7	303942		Not Available	KNOB AND SCREW
10	304595M		Not Available	FRONT PANEL-HARVEST WHEAT
11	<a href="#">Y305086</a>			Adjustable Leg And Nut
14	305190M		Not Available	TOP COVER-HARVEST WHEAT
15	<a href="#">Y305193</a>			Console
17	305193M		Not Available	CONSOLE-HARVEST WHEAT
20	305302M		Not Available	CABINET-HARVEST WHEAT

23	306668M	Not Available	DOOR, HARVEST WHEAT
24	Y310632	<a href="#">1163839</a>	Screw
25	<a href="#">Y313559</a>		Screw
28	313908M	Not Available	DOOR PANEL-HARVEST WHEAT
29	<a href="#">Y314137</a>		Foot, Rubber

