


Maytag GDE510 01 - CONTROL PANEL

MODEL DE-DG510 CONTROL PANEL



12

Maytag [Residential Maytag GDE510 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204807			Ground Wire, Supp. Plte To Top Cover
2	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
3	211168	W10139210		Screw, 8-18 X 5/16
4	213117	67006908		Screw, Ice Rack
5	214806		Not Available	CAP FOR TIMER KNOB
6	214815			End Cap F/Control Panel-LH
7	214816			End Cap F/Control Panel-RH
8	214872			Palnut, End Cap Note: Nut, Lamp Holder
9	214893		Not Available	DETENT RING F/TIMER KNOB CA
10	214894			Fastener, End Cap
11	214897			Pad, Control Panel
12	214990			Button For Switch
13	214991			Button For Switch
14	305201			Auto Dry Or Chime Switch

15	305202	Not Available	TEMPERATURE SELECTOR SWITCH
16	305205	694419	Mini-Buzzer
17	305211		Push To Start Switch
18	305449		Timer
19	305343	Not Available	MAIN WIRE HARNESS
20	305344	Not Available	MAIN WIRE HARNESS
21	305419	Not Available	CONTROL PANEL
22	312273		Nut, Control Knob
23	Y314166		Knob For Timer
24	314167	Not Available	TIMER DIAL INDICATOR
25	314177	Not Available	BRACKET FOR START SWITCH
26	314184		Back Up Plate
27	Y314322	211251	Screw, Transformer
28	910708	488234	Screw 8-32 X 1/4

