


Maytag GDE610 02 - FRONT PANEL & DOOR ASSEMBLY

MODELS DE-DG110-210-410-510-610-710-810

**FRONT PANEL & DOOR ASSEMBLY
ORIGINAL & SERIES 01**



Maytag Residential Maytag GDE610 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204439			Screw And Fstner Assembly
2	212949	22001866		Screw, Relay
3	212982	22001650		Fastener, Spring
4	302542		Not Available	PART NOT USED. (DG ONLY)
5	302542L		Not Available	PART NOT USED. (DG ONLY)
6	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
7	Y304575	W10169313		Switch-Dor
8	Y304576	W10169313		Switch-Dor
9	Y304577	33001230		Hinge, Door
10	306436			Door Latch Kit--W
13	304579M		Not Available	DOOR-HARVEST WHEAT
14	304594			Front Panel-White
15	304594L		Not Available	FRONT PANEL-ALMOND
16	304594M	3369903		Dishrack
19	304595M		Not Available	FRONT PANEL-HARVEST WHEAT

20	Y305753	W10169313		Switch-Dor
21	Y305754	W10169313		Switch-Dor
22	305835		Not Available	INNER DOOR WITH KNOB & SCRE
23	303942		Not Available	KNOB AND SCREW
24	Y310376			Clip, Door Switch Harness
25	312301		Not Available	BUSHING FOR ACCESS STUD
26	312369			Sleeve, Access Panel Stud Part Not Used
27	Y313907			Fastener, Twin
30	313908M		Not Available	DOOR PANEL-HARVEST WHEAT
31	Y313910			Clip, Door Liner To Outer Panel
32	Y313911			Door Strike Retainer
33	Y313912	306436		Door Latch Kit--W
34	Y313927			INSTRUCTION LABEL
35	Y314062			Screw, Door Hinge And Panel
36	314077			Door Seal
37	314119		Not Available	GAS IGNITION LABEL
38	314286			Seal For Front Panel
39	314347	400021-1		Screw

