


# Maytag GDE710 02 - FRONT PANEL & DOOR ASSEMBLY

**MODELS DE-DG110-210-410-510-610-710-810**

**FRONT PANEL & DOOR ASSEMBLY  
ORIGINAL & SERIES 01**



Maytag Residential Maytag GDE710 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">204439</a>			Screw And Fstner Assembly
2	212949	<a href="#">22001866</a>		Screw, Relay
3	212982	<a href="#">22001650</a>		Fastener, Spring
4	302542		Not Available	PART NOT USED. (DG ONLY)
5	302542L		Not Available	PART NOT USED. (DG ONLY)
6	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
7	Y304575	<a href="#">W10169313</a>		Switch-Dor
8	Y304576	<a href="#">W10169313</a>		Switch-Dor
9	Y304577	<a href="#">33001230</a>		Hinge, Door
10	<a href="#">306436</a>			Door Latch Kit--W
13	304579M		Not Available	DOOR-HARVEST WHEAT
14	<a href="#">304594</a>			Front Panel-White
15	304594L		Not Available	FRONT PANEL-ALMOND
16	304594M	<a href="#">3369903</a>		Dishrack
19	304595M		Not Available	FRONT PANEL-HARVEST WHEAT

20	Y305753	<a href="#">W10169313</a>		Switch-Dor
21	Y305754	<a href="#">W10169313</a>		Switch-Dor
22	305835		Not Available	INNER DOOR WITH KNOB & SCRE
23	303942		Not Available	KNOB AND SCREW
24	<a href="#">Y310376</a>			Clip, Door Switch Harness
25	312301		Not Available	BUSHING FOR ACCESS STUD
26	<a href="#">312369</a>			Sleeve, Access Panel Stud Part Not Used
27	<a href="#">Y313907</a>			Fastener, Twin
30	313908M		Not Available	DOOR PANEL-HARVEST WHEAT
31	<a href="#">Y313910</a>			Clip, Door Liner To Outer Panel
32	<a href="#">Y313911</a>			Door Strike Retainer
33	Y313912	<a href="#">306436</a>		Door Latch Kit--W
34	Y313927			INSTRUCTION LABEL
35	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
36	<a href="#">314077</a>			Door Seal
37	314119		Not Available	GAS IGNITION LABEL
38	<a href="#">314286</a>			Seal For Front Panel
39	314347	<a href="#">400021-1</a>		Screw

