


Maytag GDE8200 01 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: DE-DG8200



Issue Date: 6/90

18

[Maytag Residential Maytag GDE8200 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	314184			Back Up Plate
2	214872			Palnut, End Cap Note: Nut, Lamp Holder
3	211168	W10139210		Screw, 8-18 X 5/16
"	307305			Switch Push To Start
4	211168	W10139210		Screw, 8-18 X 5/16
"	305205	694419		Mini-Buzzer
5	207365			2 Button Switch
"	211168	W10139210		Screw, 8-18 X 5/16
6	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	204807			Ground Wire, Supp. Plite To Top Cover
7	305973			Timer
"	910708	488234		Screw 8-32 X 1/4
8	214897			Pad, Control Panel
9	207216		Not Available	END CAP RH

"	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
10	214894		Fastener, End Cap
11	215821	Not Available	CAP, KNOB
12	312273		Nut, Control Knob
13	315041		Knob, Timer
14	315042		Dial Skirt
15	307904	Not Available	CONTROL PANEL
"	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
16	Y307259		Wire Harness
"	307272		Wire Harness
17	207215	Not Available	END CAP LH

the laundry company[®]

the laundry company[®]

the laundry company[®]