


Maytag GDE8410 01 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: DE-DG8410



Issue Date: 6/90

22

[Maytag Residential Maytag GDE8410 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314184			Back Up Plate
2	214872			Palnut, End Cap Note: Nut, Lamp Holder
3	211168	W10139210		Screw, 8-18 X 5/16
"	307305			Switch Push To Start
4	305205	694419		Mini-Buzzer
"	211168	W10139210		Screw, 8-18 X 5/16
5	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	204807			Ground Wire, Supp. Plte To Top Cover
6	306040			Timer
"	910708	488234		Screw 8-32 X 1/4
7	214897			Pad, Control Panel
8	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	207216		Not Available	END CAP RH
9	214894			Fastener, End Cap

10	215821	Not Available	CAP, KNOB
11	312273		Nut, Control Knob
12	315041		Knob, Timer
13	315042		Dial Skirt
14	307951	Not Available	CONTROL PANEL
"	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
15	307945	Not Available	WIRE HARNESS
"	307946	Not Available	WIRE HARNESS
16	207215	Not Available	END CAP LH

