


Maytag GDG18CT 10 - FRONT PANEL & DOOR ASSY (SERIES 04)



Maytag Residential Maytag GDG18CT Dryer Parts Parts Diagram 10 - FRONT PANEL & DOOR ASSY (SERIES 04)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204439			Screw And Fstner Assembly
002	212949	22001866		Screw, Relay
003	212982	22001650		Fastener, Spring
004	NLA		Not Available	ACCESS DOOR (WHITE)
005	NLA		Not Available	ACCESS DOOR-ALMOND
NI	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
007	Y304576	W10169313		Switch-Dor
NI	Y304577	33001230		Hinge, Door
"	Y304579			DOOR (WHT)
"	NLA		Not Available	DOOR-ALMOND
"	NLA		Not Available	DOOR-HARVEST WHEAT
"	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
014	NLA		Not Available	INNER DOOR WITH KNOB & SCRE

NI	NLA	Not Available	KNOB AND SCREW
"	306436		Door Latch Kit--W
017	Y310376		Clip, Door Switch Harness
018	NLA	Not Available	BUSHING FOR ACCESS STUD
NI	NLA	Not Available	SCREW---NA
"	312369		Sleeve, Access Panel Stud Part Not Used
021	Y313340		LABEL, LINT SCREEN INSTRUCTION
022	Y313907		Fastener, Twin
NI	Y313908		DOOR PANEL-WHITE
024	NLA	Not Available	DOOR PANEL-ALMOND
025	NLA	Not Available	DOOR PANEL-HARVEST WHEAT
026	Y313910		Clip, Door Liner To Outer Panel
NI	Y313911		Door Strike Retainer
028	Y313927		INSTRUCTION LABEL
NI	Y314025		Latch For Access Door
"	Y314062		Screw, Door Hinge And Panel
"	314077		Door Seal
"	NLA	Not Available	GAS IGNITION LABEL
"	314286		Seal For Front Panel
"	NLA	Not Available	SCREW FOR DOOR KNOB---NA

the laundry company[®]

the laundry company[®]