


# Maytag GDG19CT 08 - CONTROL CENTER



18

Maytag [Residential Maytag GDG19CT Dryer Parts](#) Parts Diagram 08 - CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	ACCESS DOOR (WHT)
002	<a href="#">214878</a>			Latch For Access Door
003	NLA		Not Available	MAIN WIRE HARNESS
004	NLA		Not Available	HARNESS, TICKET CONTROL
005	NLA		Not Available	OUTER CASE (WHT)
006	NLA		Not Available	ACCESS DOOR (WHT)
007	<a href="#">214660</a>			Gasket, Control Center
008	NLA		Not Available	MTG. STRAP---NA
009	<a href="#">910309</a>			Washer, Mounting Strap
010	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
011	Y052740	<a href="#">62739</a>		Nut, Lock
012	<a href="#">213089</a>			Knob For Timer
013	NLA		Not Available	TIMER MOTOR
"	Y303801		Not Available	TIMER WITH KNOB AND PIN
014	212276	<a href="#">W10116760</a>		Screw