


# Maytag GDG210 03 - CONTROL PANEL



Maytag [Residential Maytag GDG210 Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
2	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
3	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
4	214806		Not Available	CAP FOR TIMER KNOB
5	<a href="#">214815</a>			End Cap F/Control Panel-LH
6	<a href="#">214816</a>			End Cap F/Control Panel-RH
7	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
8	214893		Not Available	DETENT RING F/TIMER KNOB CA
9	<a href="#">214894</a>			Fastener, End Cap
10	<a href="#">214897</a>			Pad, Control Panel
11	<a href="#">214991</a>			Button For Switch
12	305200		Not Available	TEMPERATURE SELECTOR SWITCH
13	<a href="#">305211</a>			Push To Start Switch

14	305447	Not Available	TIMER
15	305339	Not Available	MAIN WIRE HARNESS
16	305340	Not Available	MAIN WIRE HARNESS
17	305417	Not Available	CONTROL PANEL
18	<a href="#">312273</a>		Nut, Control Knob
19	<a href="#">Y314166</a>		Knob For Timer
20	314167	Not Available	TIMER DIAL INDICATOR
21	314177	Not Available	BRACKET FOR START SWITCH
22	<a href="#">314184</a>		Back Up Plate
23	Y314322	<a href="#">211251</a>	Screw, Transformer
24	910708	<a href="#">488234</a>	Screw 8-32 X 1/4

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>