


# Maytag GDG24CS 04 - REAR VIEW



Maytag [Residential Maytag GDG24CS Dryer Parts](#) Parts Diagram 04 - REAR VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	<a href="#">62739</a>		Nut, Lock
002	<a href="#">Y201808</a>			Converter
003	<a href="#">204439</a>			Screw And Fstner Assembly
004	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
005	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
006	212276	<a href="#">W10116760</a>		Screw
007	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
008	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
009	<a href="#">301548</a>			Clamp, Ground Wire
010	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
011	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
NI	NLA		Not Available	SCREW & WASHER ASSY.

"	NLA	Not Available	FRONT PANEL-WHITE
"	NLA	Not Available	FRONT PANEL-ALMOND
"	NLA	Not Available	FRONT PANEL-HARVEST WHEAT
"	<a href="#">Y305086</a>		Adjustable Leg And Nut
"	Y305191	Not Available	TOP COVER-WHITE
019	NLA	Not Available	TOP COVER-ALMOND
NI	NLA	Not Available	TOP COVER-HARVEST WHEAT
"	NLA	Not Available	CABINET-WHITE
"	NLA	Not Available	CABINET-ALMOND
"	NLA	Not Available	CABINET-HARVEST WHEAT
"	NLA	Not Available	CONTROL COVER (WHT)
"	NLA	Not Available	CONTROL COVER ASSY---NA
"	NLA	Not Available	CONTROL COVER ASSY
"	<a href="#">311155</a>		Ground Wire And Clamp
038	Y312905	Not Available	COVER, TERMINAL
039	Y312951	Not Available	ACCESS COVER, BACK
040	<a href="#">313122</a>		Screw - Baffle To Tumbler
041	<a href="#">Y313559</a>		Screw
043	<a href="#">Y314137</a>		Foot, Rubber

