


Maytag GDG27CT 04 - CONTROL CENTER SHROUD

SECTION: CONTROL CENTER SHROUD - CT
 MODEL: DE-DG27CT



Maytag [Residential Maytag GDG27CT Dryer Parts](#) Parts Diagram 04 - CONTROL CENTER SHROUD
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SPACER FOR ADVANCE RELAY
002	NLA		Not Available	SPRING LEVER FOR RELAY
003	212276	W10116760		Screw
"	212949	22001866		Screw, Relay
"	NLA		Not Available	RELAY BRACKET
004	212950	M0227520		Screw-Tc No.6-32 X 13/16", Preform SwiTch
"	Y303787		Not Available	SWITCH FOR RELAY
005	212276	W10116760		Screw
"	Y314261			Switch And Relay Bracket
006	312751			Lockwasher, Start Switch
007	205663			Knob For Selector Switch
008	Y312706	422617		Nut
009	Y312702			Knurled Nut, Start Switch
010	NLA		Not Available	INSULATOR
011	307253			Switch, Cycle Selector

"	Y313588	488234		Screw 8-32 X 1/4
012	306941	W10149462		Switch, Push-To-Start
013	212951			Screw, No.6-32 X 1/4 Inch
"	305393			Solenoid For Relay Assembly
014	303963		Not Available	LIGHT, INDICATOR
015	315037		Not Available	PANEL, VAULT
"	Y313424			Screw, Vault Panel
016	NLA		Not Available	OUTER CASE-WHITE
017	Y052740	62739		Nut, Lock
018	213648	98165		Screw
"	NLA		Not Available	CONTROL SHROUD-WHITE
019	212276	W10116760		Screw
"	NLA		Not Available	MTG. STRAP----NA
020	Y313671	33001303		Grommet, Plate Hole
021	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	305534		Not Available	VAULT ASSEMBLY
"	Y310632	1163839		Screw
"	Y313559			Screw
022	211168	W10139210		Screw, 8-18 X 5/16
"	910768	M0280301		Tie Electr
023	Y313427	206637		Lock Kit
024	NLA		Not Available	SPRING WASHER FOR LOCK
025	211168	W10139210		Screw, 8-18 X 5/16
"	Y303981			Ground Wire For Latch
026	Y313427	206637		Lock Kit
027	212328	W10139762		Hex Nut, 3/4-27

the laundry company[®]

the laundry company[®]