


**Maytag GDG33CM 04 - DOOR SWITCH, TEMP CONTROL & TERMINAL  
BLK**



Maytag Residential Maytag GDG33CM Dryer Parts Parts Diagram 04 - DOOR SWITCH, TEMP CONTROL & TERMINAL BLK

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">210866</a>			Nut, Twin Speed
NI	NLA		Not Available	CAGE NUT
003	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
004	213966	<a href="#">3400014</a>		Screw
005	214884	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
006	<a href="#">Y330073</a>			Valve, Shut-Off
007	<a href="#">Y330078</a>			Cool-Down Bypass Switch
008	Y330083		Not Available	CONTROL, TEMPERATURE
009	<a href="#">Y330092</a>			Terminal Block
NI	NLA		Not Available	HINGE, DOOR
011	<a href="#">Y330226</a>			Wire, Ignition Control Assembly
012	<a href="#">Y330228</a>			Harness For Gas Valve
013	<a href="#">Y330230</a>			Ignition Control Assembly
014	<a href="#">Y330231</a>			Transformer

NI	Y330232		Not Available	DOOR SWITCH
016	Y330241		Not Available	PANEL, FRONT (WHITE)
017	330241L		Not Available	(ALMOND)
NI	NLA		Not Available	(H. WHEAT)
019	Y330242		Not Available	VAULT ASSEMBLY
020	<a href="#">Y330253</a>			Fuse
021	<a href="#">Y330254</a>			Fuse Block
022	Y330294			COIN BOX ASSEMBLY
NI	NLA		Not Available	SCREW, BRACKET (VAULT)
024	331014	<a href="#">8281196</a>		Screw
NI	NLA		Not Available	CABLE CLAMP
026	331026	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
027	331032	<a href="#">61002031</a>		Screw, Handle
028	<a href="#">331036</a>			Washer-Front Panel Screws
029	<a href="#">331058</a>			Grommet-Temp. Control Tubin
030	<a href="#">331061</a>			Knob For Temperature Contro
NI	NLA		Not Available	GAS SUPPLY LINE-28 1/2 INCH
032	331084		Not Available	SUPPORT ROD FOR UPPER DOOR
NI	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
034	<a href="#">331151</a>			Lever-Temperature Control
035	<a href="#">331167</a>			Gasket For Door-Outer
NI	NLA		Not Available	NUT, CONDUIT
"	NLA		Not Available	GROMMET, TEMP. CONTROL TUBIN
038	331193		Not Available	COVER FOR DOOR SWITCH BOX
NI	331197		Not Available	SHIELD FOR DOOR SWITCH
040	<a href="#">331198</a>			Actuator For Door Switch
041	331199		Not Available	GASKET FOR DOOR GLASS
NI	<a href="#">331201</a>			Door Switch Box
043	331204	<a href="#">61003351</a>		Screw, Handle To Frame
NI	NLA		Not Available	SCREW
"	NLA		Not Available	TWIN FASTENER
"	NLA		Not Available	WASHER, COIN BOX LOCK
"	NLA		Not Available	TWIN FASTENER W/SCREWS

