


# Maytag GDG34CQ 04 - DOOR, DOOR SWITCH, & COIN BOX



Maytag Residential Maytag GDG34CQ Dryer Parts Parts Diagram 04 - DOOR, DOOR SWITCH, & COIN BOX  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">210720</a>			Rivet, Bearing To Tumbler Frmt
002	Y330232		Not Available	DOOR SWITCH
003	<a href="#">Y330275</a>			Door Assembly
NI	NLA		Not Available	COIN BOX, WHITE
"	330276L		Not Available	COIN BOX-ALMOND
"	NLA		Not Available	COIN BOX - HARVEST WHEAT
"	NLA		Not Available	HINGE ASSEMBLY-WHITE
"	NLA		Not Available	HINGE ASSEMBLY-ALMOND
"	NLA		Not Available	HINGE ASSEMBLY-HARVEST WHEA
"	NLA		Not Available	FRONT PANEL-WHITE
"	NLA		Not Available	FRONT PANEL-ALMOND
020	331199		Not Available	GASKET FOR DOOR GLASS
NI	NLA		Not Available	SCREW
"	331197		Not Available	SHIELD FOR DOOR SWITCH
"	NLA		Not Available	TWIN FASTENER

"	<a href="#">331198</a>		Actuator For Door Switch
"	NLA	Not Available	FRONT PANEL-WHITE
029	331204	<a href="#">61003351</a>	Screw, Handle To Frame
"	<a href="#">331245</a>		Catch For Door
030	331193	Not Available	COVER FOR DOOR SWITCH BOX
"	331246	Not Available	GLASS FOR DOOR
NI	NLA	Not Available	FRONT PANEL-HARVEST WHEAT
"	331243L	Not Available	FRONT PANEL-ALMOND
"	NLA	Not Available	SCREW FOR DOOR HANDLE
033	<a href="#">331201</a>		Door Switch Box
"	<a href="#">331250</a>		Stud For Door Catch
NI	331252	<a href="#">3400094</a>	Screw, 10-32 X 3/8
"	NLA	Not Available	HINGE STRAP-HARVEST WHEAT
"	331253	<a href="#">3400029</a>	Nut, Adapter Plate
"	NLA	Not Available	FRONT PANEL-HARVEST WHEAT
042	331251	<a href="#">Y707702</a>	Locknut
"	<a href="#">331256</a>		Screw
NI	NLA	Not Available	HINGE STRAP-WHITE
"	<a href="#">331167</a>		Gasket For Door-Outer
"	331258	Not Available	LATCH FOR COIN BOX
"	<a href="#">331254L</a>		Hinge Strap-Almond
"	NLA	Not Available	WASHER FOR LOCK
"	NLA	Not Available	WASHER - UNDER LOCK HEAD

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>