


Maytag GDG382 02 - FRONT PANEL & DOOR ASSEMBLY



Maytag Residential Maytag GDG382 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204439			Screw And Fstner Assembly
2	212949	22001866		Screw, Relay
3	212982	22001650		Fastener, Spring
6	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
7	303942		Not Available	KNOB AND SCREW
8	Y304577	33001230		Hinge, Door
11	304594M	3369903		Dishrack
12	Y305753	W10169313		Switch-Dor
13	306436			Door Latch Kit--W
16	306668M		Not Available	DOOR, HARVEST WHEAT
17	306676		Not Available	INNER DOOR WITH KNOB
18	Y310376			Clip, Door Switch Harness
19	312301		Not Available	BUSHING FOR ACCESS STUD
20	312369			Sleeve, Access Panel Stud Part Not Used

21	Y313907		Fastener, Twin
24	313908M	Not Available	DOOR PANEL-HARVEST WHEAT
25	Y313910		Clip, Door Liner To Outer Panel
26	Y313911		Door Strike Retainer
27	Y313927		INSTRUCTION LABEL
28	Y314062		Screw, Door Hinge And Panel
29	314077		Door Seal
30	314119	Not Available	GAS IGNITION LABEL
31	314286		Seal For Front Panel
32	314347	400021-1	Screw

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®