


Maytag GDG382 03 - FRONT VIEW



Maytag [Residential Maytag GDG382 Dryer Parts](#) Parts Diagram 03 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	62739		Nut, Lock
2	204439			Screw And Fstner Assembly
3	204445			Screw And Fastener Assembly
4	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	213007			Xfor Cabinet See Cabinet, Back
8	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
9	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
10	303942		Not Available	KNOB AND SCREW
13	304594M	3369903		Dishrack
14	Y305086			Adjustable Leg And Nut
17	305190M		Not Available	TOP COVER-HARVEST WHEAT
20	305193M		Not Available	CONSOLE-HARVEST WHEAT
23	305302M		Not Available	CABINET-HARVEST WHEAT

26	306668M		Not Available	DOOR, HARVEST WHEAT
27	Y310632	1163839		Screw
28	Y313559			Screw
32	Y314137			Foot, Rubber
"	313908M		Not Available	DOOR PANEL-HARVEST WHEAT

