



Maytag Residential Maytag GDG382 Dryer Parts Parts Diagram 08 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	62739		Nut, Lock
2	Y201808			Converter
3	204439			Screw And Fstner Assembly
4	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
5	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	211881			Grommet, Cord Part Not Used- Gas Models Only
7	213007			Xfor Cabinet See Cabinet, Back
8	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
9	215075			Fastener, Control Panel To Console
10	301548			Clamp, Ground Wire
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY

12	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
13	303846	22003781		Screw, Ground Strap
14	Y304122		Not Available	POWER CORD-5 FT, 3 WIRE
17	304594M	3369903		Dishrack
18	Y305086			Adjustable Leg And Nut
21	305190M		Not Available	TOP COVER-HARVEST WHEAT
24	305193M		Not Available	CONSOLE-HARVEST WHEAT
27	305302M		Not Available	CABINET-HARVEST WHEAT
28	Y310632	1163839		Screw
29	311155			Ground Wire And Clamp
30	Y311270			Washer, Terminal Block
31	Y311423	489483		Screw 10-32 X 1/2
32	311484	112432		Nut
33	Y312184			Strap, Grounding
34	Y312209	W10001200		Screw
35	Y312904			Bracket, Terminal Block
36	Y312905		Not Available	COVER, TERMINAL
37	Y312951		Not Available	ACCESS COVER, BACK
38	313122			Screw - Baffle To Tumbler
39	Y313559			Screw
40	Y313561			Screw---NA
41	Y314137			Foot, Rubber
42	400008			Block, Terminal

the laundry company®

the laundry company®