


Maytag GDG4000 01 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: DE-DG4000



Issue Date: 6/90

2

Maytag Residential Maytag GDG4000 Dryer Parts Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314184			Back Up Plate
2	214872			Palnut, End Cap Note: Nut, Lamp Holder
3	305205	694419		Mini-Buzzer
"	211168	W10139210		Screw, 8-18 X 5/16
4	204807			Ground Wire, Supp. Plte To Top Cover
"	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	308088		Not Available	TIMER
"	306483			Timer
"	910708	488234		Screw 8-32 X 1/4
6	214897			Pad, Control Panel
7	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	314727	207927		End Cap, Control Panel
8	214894			Fastener, End Cap
9	314723	W10133501		Cap, Knob

10	312273		Nut, Control Knob
11	314724		Knob For Timer
12	314725	33001500	Dial, Timer Indicator
13	307747	Not Available	CONTROL PANEL
"	Y308093		Control Panel Assembly
"	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
14	307303	Not Available	WIRE HARNESS
"	308086		Wire Harness
15	314726	Not Available	END CAP - LEFT HAND
16	211168	W10139210	Screw, 8-18 X 5/16
"	307305		Switch Push To Start

the laundry company[®]

the laundry company[®]

the laundry company[®]