


Maytag GW18F1A 02 - CONTROL PANEL (REV. A-D)



Maytag Residential Maytag GW18F1A Washer Parts Parts Diagram 02 - CONTROL PANEL (REV. A-D)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33-9668-24		Not Available	WRAPPER
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE SCREW-PURCHASED LOCALLY
2	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE SCREW-PURCHASED LOCALLY
"	25-7435	33002917		Screw, No.10-16
"	33-3701		Not Available	BACKGUARD PAD
"	33-4062		Not Available	REINFORCE PLATE
"	33-8909		Not Available	SHIELD
"	34-9487		Not Available	PLATE, REINFORCEMENT
3	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE LOCKWASHER (PURCHASED LOCALLY)
"	35-0330		Not Available	CONTROL PANEL
"	25-7760			Screw
4	33-7191			LH End Cap
5	25-7496	25-7760		Screw

"	33-7190		Not Available	RH END CAP
6	53-0243		Not Available	CONTROL SHIELD
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE WASHER (PURCHASED LOCALLY)
"	25-7461		Not Available	CLIP
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	35-0484		Not Available	TIMER
"	35-0033			Timer
"	35-0115			Timer Motor 1 RPM
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE SCREW-PURCHASED LOCALLY
9	35-0467	12500057		Knob Ski
10	25-6044			Set Screw
"	33-7508			Timer Knob
"	35-0494	12500057		Knob Ski
11	35-0514		Not Available	NAMEPLATE
"	35-0447		Not Available	NAMEPLATE
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-0470		Not Available	NAMEPLATE
"	35-0110		Not Available	PRESSURE SWITCH
"	35-0339		Not Available	NAMEPLATE
"	35-0340		Not Available	NAMEPLATE
"	35-0341		Not Available	NAMEPLATE
"	35-0515		Not Available	NAMEPLATE
"	35-0513		Not Available	NAMEPLATE

