


Maytag GW18G1A 02 - CONTROL PANEL



ISSUED 3/89

Maytag Residential Maytag GW18G1A Washer Parts Parts Diagram 02 - CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-1072		Not Available	CONTROL PANEL
2	53-0265			LH Endcap
"	53-0264			RH Endcap
3	25-7851			Speedclip, End Cap To Top
"	25-7649	910187		Screw
"	25-7697	25-2219		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	34-9487		Not Available	PLATE, REINFORCEMENT
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0279		Not Available	TRIM, END CAP (RT)
"	53-0280		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control Panel

8	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-0365	53-1676	Shield, Control
10	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457		Screw, Sems
"	25-7853	25-7933	Ring, Retaining
"	53-0268	21001460	Shield, Rear
11	35-0484	Not Available	TIMER
"	35-0115		Timer Motor 1 RPM
12	25-0088	489483	Screw 10-32 X 1/2
13	35-0679	12500057	Knob Ski
14	35-0496	12500057	Knob Ski
15	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-0781	Not Available	PRESSURE SWITCH
16	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE SELECTOR KNOB

