


Maytag HAV3460AWW 03 - CONTROL PANEL



Maytag [Residential Maytag HAV3460AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|-----------------------|--------|---|
| 1 | 21001992 | | | Panel, Control |
| 2 | 21001519 | | | Endcap |
| " | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 3 | 21001523 | | | Endcap |
| " | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 4 | 21001226 | | | Switch, Water Temp. 4 Position |
| 5 | 21001882 | | | Switch, Pressure |
| 6 | 21001984 | | | Skirt, Timer Knob |
| 7 | 21001985 | | | Knob, Timer |
| 8 | 21001960 | | | Switch, Speed |
| 9 | 21001965 | | | Frame, Control Panel, Support |
| 10 | 21001527 | | | Shield, Rear |
| " | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 25-3457 | | | Screw, Sems |

| | | | |
|----|--------------------------|--------------------------|--|
| 11 | 25-3092 | 90767 | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 21001959 | | Timer |
| 12 | 21001986 | 21002070 | Knob, Selector |
| 13 | 21001603 | | Shield, Control |
| " | 21001517 | | Shield, Control |
| 14 | 21001993 | | Switch, Rotary |
| 15 | 53-1639 | | Buzzer Assembly |
| 16 | 21001994 | | Harness, Wiring |
| " | 21001979 | | Lead Assembly |
| " | 21001980 | | Lead Assembly |

Howes
the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]