


# Maytag HAV4657AWW 03 - CONTROL PANEL



Maytag Residential Maytag HAV4657AWW Washer Parts Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21001976</a>			Panel, Control
2	<a href="#">21001519</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">21001523</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">21001960</a>			Switch, Speed
5	<a href="#">21001882</a>			Switch, Pressure
6	21001971	<a href="#">21001600</a>		Skirt, Timer
7	<a href="#">21001972</a>			Knob, Timer
8	<a href="#">21001852</a>			Switch, Temperature
9	<a href="#">21001965</a>			Frame, Control Panel, Support
10	<a href="#">21001527</a>			Shield, Rear
11	<a href="#">21001959</a>			Timer
12	21001974	<a href="#">21002196</a>		Knob-Selector
13	<a href="#">21001603</a>			Shield, Control

"	<a href="#">21001517</a>		Shield, Control
14	22003977	<a href="#">74010226</a>	Switch, Rocker W/Shield
15	<a href="#">22003981</a>		Switch, Momentary Rocker
16	<a href="#">53-1639</a>		Buzzer Assembly
17	<a href="#">31001443</a>		Switch, Two Pos Rotary
18	<a href="#">21001981</a>		Lead Assembly
"	<a href="#">21001966</a>		Harness, Wiring
"	<a href="#">21001978</a>		Lead Assembly
"	<a href="#">21001979</a>		Lead Assembly

