



[Maytag Residential Maytag LA110 Washer Parts Diagram 01 - 50HZ PARTS \(A110\)](#)
[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------|---------------|--------------------------|
| 1 | Y202496 | | | Pulley, Motor |
| 2 | 211948 | | | V Belt, Drive Pulley |
| 3 | 211451 | | | Belt, Pump |
| 4 | 201408 | | | Capacitor 120-50 |
| 5 | 211149 | | | Clip, Capacitor |
| 6 | 205613 | | | Water Valve |
| 7 | 203237 | | | No.17 Wire With Terminal |
| 8 | Y202496 | | | Pulley, Motor |
| 9 | 211948 | | | V Belt, Drive Pulley |
| 10 | 211451 | | | Belt, Pump |
| 11 | 201101 | | | Capacitor |
| 12 | 211149 | | | Clip, Capacitor |
| 13 | Y205684 | | Not Available | WATER VALVE 240-50 |
| 14 | 203237 | | | No.17 Wire With Terminal |
| 15 | 206092 | | | Timer 240-50 |