



Maytag [Residential Maytag LA110 Washer Parts](#) Parts Diagram 07 - TRANSMISSIONS
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|-------------------------------|
| 1 | Y014827 | | | Washer-Center Shaft |
| 2 | Y014839 | | | Collar-Drive Shaft |
| 3 | Y015629 | | | Bolt, Grinding Chamber |
| 4 | 015639 | | | Dowel Pin |
| 5 | Y015902 | | | Spring For Agitator |
| 6 | Y052740 | 62739 | | Nut, Lock |
| 7 | Y056080 | 6-0560800 | | Oil |
| 8 | 200730 | 22002124 | | Shaft- Agi |
| 9 | 200813 | | Not Available | GEAR CASE COVER ASSEMBLY |
| 10 | 201463 | | Not Available | PITMAN WITH WRIST PIN |
| 11 | 203162 | | | Gear Housing W/Studs And Tube |
| 12 | 203193 | | Not Available | GEAR HOUSING W/STUDS & TUBE |
| 13 | 203383 | W10172458 | | Transmison |
| 14 | 203438 | W10172457 | | Transmison |

| | | | |
|----|------------------------|---------------------------|-----------------------------|
| 15 | 204967 | | Gear Kit-Power Fin Agitator |
| 16 | 205811 | | Counterweight |
| 17 | 210054 | | Pinion |
| 18 | 210172 | | Lock Washer |
| 19 | 210179 | | Retaining Ring |
| 20 | 210183 | | Groove Pin |
| 21 | 210286 | | Seal |
| 22 | 210315 | | Pinion |
| 23 | 210632 | 22210632 | Gasket |
| 24 | 210670 | | Segment |
| 25 | 210690 | | Seal, Rubber |
| 26 | 211089 | | Lug, Stop Pulley |
| 27 | 211090 | 22003555 | Washer, Stop Lug |
| 28 | 211375 | 681582 | Screw |
| 29 | 211483 | 6-2114830 | Washer- SP |
| 30 | 211484 | | Washer, Lug |
| 31 | 211486 | | Screw, 3/8-16 X 1/2 Inch |
| 32 | 211487 | | Groov-Pin |
| 33 | 212988 | | Part Not Used |
| 34 | 213044 | | Shaft, Center |
| 35 | 213068 | 204967 | Gear Kit-Power Fin Agitator |
| 36 | 214276 | Not Available | WASHER FOR GEARS |

