


Maytag LA209S 06 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag LA209S Washer Parts Parts Diagram 06 - TOP COVER, CONSOLE & LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205997			Non-Bleach Conversion Kit
2	Y201808			Converter
3	204445			Screw And Fastener Assembly
4	204968			Plunger And Bracket Assembly--W
5	205056	204590		Cord, Power
6	205415	279347		Switch-Lid
8	205538L		Not Available	TOP COVER-ALMOND
10	205635L		Not Available	CONSOLE (ALM)
11	205821		Not Available	MAIN WIRE HARNESS
13	210186	3370225		Screw
14	211294	90767		Screw, 8A X 3/8 Hex Washer Head Tapping
15	211500			Washer, Bracket To Top Cover
16	211726			Hinge, Ball Lid
17	211737	248562		Terminal
18	211881			Grommet, Cord Part Not Used-

19	411001		Gas Models Only
20	212073L	Not Available	LID-ALMOND
21	212716		Bumper, Lid
22	213718		Plunger, Lid Switch
23	213720		Spring, Lid Switch
24	214804		Unbalance Lever
25	214805		Pin For Unbalance Lever
26	214813	Not Available	LEVER FOR LID SWITCH
27	214884	213501	Screw, No.6-20 X 1-1/8 Inch
28	214898		Cover For Lid Switch
29	214987		Moisture Barrier For Switch
30	215075		Fastener, Control Panel To Console
31	301548		Clamp, Ground Wire
32	311155		Ground Wire And Clamp
33	Y312140		Wire Connector
34	Y313559		Screw
35	410635		Fastener
36	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
37	911267		Screw, Pump Cover

