


Maytag LA210S 06 - TOP COVER\CONSOLE\LID SWITCH



Maytag Residential Maytag LA210S Washer Parts Parts Diagram 06 - TOP COVER\CONSOLE\LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y201808			Converter
2	204445			Screw And Fastener Assembly
3	204968			Plunger And Bracket Assembly--W
4	205056	204590		Cord, Power
5	205415	279347		Switch-Lid
7	205537L			Top Cover-Almond--NA
9	205635L		Not Available	CONSOLE (ALM)
10	205816		Not Available	MAIN WIRE HARNESS
11	205915		Not Available	SUDS SAVE HARNESS
12	210186	3370225		Screw
13	211294	90767		Screw, 8A X 3/8 Hex Washer Head Tapping
14	211500			Washer, Bracket To Top Cover
15	211726			Hinge, Ball Lid
16	211737	248562		Terminal
17	211881			Grommet, Cord Part Not Used-

17	211001		Gas Models Only
19	212073L	Not Available	LID-ALMOND
20	212716		Bumper, Lid
21	213718		Plunger, Lid Switch
22	213720		Spring, Lid Switch
25	214804		Unbalance Lever
26	214805		Pin For Unbalance Lever
27	214813	Not Available	LEVER FOR LID SWITCH
28	214884	213501	Screw, No.6-20 X 1-1/8 Inch
29	214898		Cover For Lid Switch
30	214987		Moisture Barrier For Switch
31	215075		Fastener, Control Panel To Console
32	301548		Clamp, Ground Wire
33	311155		Ground Wire And Clamp
34	Y312140		Wire Connector
35	Y313559		Screw
36	410635		Fastener
37	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
38	911267		Screw, Pump Cover

