


Maytag LA211 04 - CONTROL PANEL



Maytag [Residential Maytag LA211 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206231			Wire Harness
3	211168	W10139210		Screw, 8-18 X 5/16
4	206222		Not Available	INFINITE WATER LEVEL SWITCH
5	410296	596669		Clamp, Manifold
6	212942	22001619		Tube, Water Level Switch
7	205033	22205033		Motor- Tim
8	206230			Timer
9	213117	67006908		Screw, Ice Rack
10	215211			Button For Switch
11	206216			Water Temperature Switch
13	214897			Pad, Control Panel
14	214872			Palnut, End Cap Note: Nut, Lamp Holder
15	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
16	214816			End Cap F/Control Panel-RH

17	214894		Fastener, End Cap
18	213966	3400014	Screw
19	211065		Spring, Index Wheel
20	211605		Bezel, Timer Dial
21	215164	Not Available	CAP FOR KNOB
22	215162		Timer Knob
23	215161	22001571	Bezel, Timer Dial
24	214809		Back Up Plate
25	206559	Not Available	CONTROL PANEL
26	214815		End Cap F/Control Panel-LH

