


# Maytag LA211S 04 - CONTROL PANEL



4

Maytag Residential Maytag LA211S Washer Parts Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

| Item | Original Part Number   | Replaced By               | Status        | Part Description                                |
|------|------------------------|---------------------------|---------------|---|
| 1    | <a href="#">206231</a> |                           |               | Wire Harness                                    |
| 3    | 211168                 | <a href="#">W10139210</a> |               | Screw, 8-18 X 5/16                              |
| 4    | 206222                 |                           | Not Available | INFINITE WATER LEVEL SWITCH                     |
| 5    | 410296                 | <a href="#">596669</a>    |               | Clamp, Manifold                                 |
| 6    | 212942                 | <a href="#">22001619</a>  |               | Tube, Water Level Switch                        |
| 7    | 205033                 | <a href="#">22205033</a>  |               | Motor- Tim                                      |
| 8    | 206236                 |                           | Not Available | TIMER   |
| 9    | 213117                 | <a href="#">67006908</a>  |               | Screw, Ice Rack                                 |
| 10   | <a href="#">215211</a> |                           |               | Button For Switch                               |
| 11   | <a href="#">206216</a> |                           |               | Water Temperature Switch                        |
| 13   | <a href="#">214897</a> |                           |               | Pad, Control Panel                              |
| 14   | <a href="#">214872</a> |                           |               | Palnut, End Cap Note: Nut, Lamp Holder          |
| 15   | <a href="#">210932</a> |                           |               | Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct |
| 16   | <a href="#">214816</a> |                           |               | End Cap F/Control Panel-RH                      |

|    |                        |                          |                            |
|----|------------------------|--------------------------|----------------------------|
| 17 | <a href="#">214894</a> |                          | Fastener, End Cap          |
| 18 | 213966                 | <a href="#">3400014</a>  | Screw                      |
| 19 | <a href="#">211065</a> |                          | Spring, Index Wheel        |
| 20 | <a href="#">211605</a> |                          | Bezel, Timer Dial          |
| 21 | 215164                 | Not Available            | CAP FOR KNOB               |
| 22 | <a href="#">215162</a> |                          | Timer Knob                 |
| 23 | 215161                 | <a href="#">22001571</a> | Bezel, Timer Dial          |
| 24 | <a href="#">214809</a> |                          | Back Up Plate              |
| 25 | 206560                 | Not Available            | CONTROL PANEL              |
| 26 | <a href="#">214815</a> |                          | End Cap F/Control Panel-LH |

