



Maytag [Residential Maytag LA212 Washer Parts](#) Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205033	<a href="#">22205033</a>		Motor- Tim
2	<a href="#">206216</a>			Water Temperature Switch
3	206222		Not Available	INFINITE WATER LEVEL SWITCH
5	<a href="#">206230</a>			Timer
7	206559		Not Available	CONTROL PANEL
9	206630	<a href="#">569869</a>		Thermostat
10	206631		Not Available	CONTROL PANEL
11	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
12	<a href="#">211065</a>			Spring, Index Wheel
13	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
14	<a href="#">211605</a>			Bezel, Timer Dial
15	213117	<a href="#">67006908</a>		Screw, Ice Rack
16	213966	<a href="#">3400014</a>		Screw
17	214806		Not Available	CAP FOR TIMER KNOB
18	<a href="#">214815</a>			End Cap F/Control Panel-LH

19	<a href="#">214816</a>		End Cap F/Control Panel-RH
20	<a href="#">214872</a>		Palnut, End Cap Note: Nut, Lamp Holder
21	<a href="#">214894</a>		Fastener, End Cap
22	<a href="#">214897</a>		Pad, Control Panel
23	215161	<a href="#">22001571</a>	Bezel, Timer Dial
24	<a href="#">215162</a>		Timer Knob
25	215164	Not Available	CAP FOR KNOB

