


Maytag LA26CD 01 - CONTROL PANEL



Maytag Residential Maytag LA26CD Washer Parts Parts Diagram 01 - CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	206780			Control Cover Assembly
"	206780L	206780		Control Cover Assembly
"	NLA		Not Available	CONTROL COVER ASSY
002	207766			Transformer
003	212276	W10116760		Screw
004	Y313559			Screw
005	203263	22004474		Switch- Pr
006	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
007	410296	596669		Clamp, Manifold
008	212942	22001619		Tube, Water Level Switch
009	215003			Fastener, Panel And Bracket
010	206828			Battery
"	912077			Locknut, Reader Harness
"	NLA		Not Available	CIRCUIT BOARD ASSY
011	Y215513			Standoff, Circuit Board
				Push Button And Switch

012	206808	W10135389		PUSH BUTTON AND SWITCH Assembly
"	215517	W10131113		Push Button
013	215527	W10140652		Screw, 6-20 X 1/2
014	215519			Panel, Control
015	215506			Screw, Control Panel Overlay
016	215515		Not Available	COVER, DISPLAY
017	214610			Bumper, Lid
018	215526			Screw, Circuit Board
019	Y314322	211251		Screw, Transformer
020	205810			Wire, Ground
021	206825	215516		Plate, Back-Up
"	NLA		Not Available	BACK BRACKET ASSY
022	206824	W10133335		Relay, Motor
023	206421			Relay, Motor Reversing
"	212949	22001866		Screw, Relay
024	203188		Not Available	TIMER ACCESS DOOR (WHT)
"	203188L		Not Available	ACCESS DOOR-ALMOND
"	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
025	207940	22001407		Case, Coin Slide
"	207940L	22001408		(ALM)
"	NLA		Not Available	CONTROL CENTER CASE HARVEST WH
026	214660			Gasket, Control Center
027	NLA		Not Available	MTG. STRAP---NA
028	910309			Washer, Mounting Strap
029	NLA		Not Available	WIRE HARNESS NLA

the laundry company[®]

the laundry company[®]