


Maytag LA283 06 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag LA283 Washer Parts Parts Diagram 06 - TOP COVER, CONSOLE & LID SWITCH
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y201808			Converter
2	204445			Screw And Fastener Assembly
3	204968			Plunger And Bracket Assembly--W
4	205056	204590		Cord, Power
5	205415	279347		Switch-Lid
7	205538L		Not Available	TOP COVER-ALMOND
10	205635L		Not Available	CONSOLE (ALM)
12	206234		Not Available	WIRE HARNESS
13	210186	3370225		Screw
14	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
15	211500			Washer, Bracket To Top Cover
16	211726			Hinge, Ball Lid
17	211737	248562		Terminal
18	211881			Grommet, Cord Part Not Used-Gas Models Only

20	212073L	Not Available	LID-ALMOND
37	212716		Bumper, Lid
38	213718		Plunger, Lid Switch
39	213720		Spring, Lid Switch
40	214805		Pin For Unbalance Lever
41	214813	Not Available	LEVER FOR LID SWITCH
42	214884	213501	Screw, No.6-20 X 1-1/8 Inch
43	214898		Cover For Lid Switch
"	215075		Fastener, Control Panel To Console
44	215236	214804	Unbalance Lever
"	214987		Moisture Barrier For Switch
45	301548		Clamp, Ground Wire
46	311155		Ground Wire And Clamp
47	Y312140		Wire Connector
48	Y313559		Screw
49	410635		Fastener
50	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
51	911267		Screw, Pump Cover

