


Maytag LA284 07 - TOP COVER, CONSOLE & LID SWITCH (SER 11)



Maytag Residential Maytag LA284 Washer Parts Parts Diagram 07 - TOP COVER, CONSOLE & LID SWITCH (SER 11)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y201808			Converter
2	204445			Screw And Fastener Assembly
3	205056	204590		Cord, Power
4	205415	279347		Switch-Lid
6	205635L		Not Available	CONSOLE (ALM)
8	205997			Non-Bleach Conversion Kit
9	206234		Not Available	WIRE HARNESS
10	207159	489355		Screw, 8 X 1/2
12	207170L			Top Cover Assembly ALM---NA
14	210186	3370225		Screw
15	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	211500			Washer, Bracket To Top Cover
17	211726			Hinge, Ball Lid
18	211737	248562		Terminal
19	211881			Grommet, Cord Part Not Used-

19	211001		Gas Models Only
21	212073L	Not Available	LID-ALMOND
23	212716		Bumper, Lid
24	213501		Screw, No.6-20 X 1-1/8 Inch
25	213720		Spring, Lid Switch
26	214279	204968	Plunger And Bracket Assembly--W
27	214436		Gasket
29	215075		Fastener, Control Panel To Console
30	Y215699	22001678	Bracket, Switch And Fuse
31	215700	Not Available	LID SWITCH PLUNGER
32	215704		Lever, Unbalance
33	301548		Clamp, Ground Wire
34	311155		Ground Wire And Clamp
35	Y312140		Wire Connector
36	Y313559		Screw
37	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

