



[Maytag Residential Maytag LA302 Washer Parts](#) Parts Diagram 05 - MOTOR MOUNT, BASE FRAME & CENTER SPRING

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200744	W10175939		Bolt
2	200816	6-2008160		Pulley- MO
3	201455			Damper
4	201639			Upper Motor Mount
5	201674		Not Available	LOWER MOTOR MOUNT---- NA
6	201698		Not Available	TUB BRACE
7	201727		Not Available	BASE FRAME WITH PADS
9	201805	12002351		Motor-Drve
10	202608	213737		Shield, Motor
11	202718			Springs, Tension
12	210186	3370225		Screw
13	210587	W10116760		Screw
14	211100			Washer, Outer Tub
15	211124			Part Not Used
16	211125			V Belt, Drive Pulley

17	211155		Washer
18	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
19	211335		Damper Pad - Felt
20	211881		Grommet, Cord Part Not Used- Gas Models Only
21	211944		Eyebolts
22	211949		Nut, Adjustment Eyebolt
23	211952	205000	Roller And Spring Kit 4+Spr
24	211953		Centering Spring
25	212142	Not Available	BRACKET -MOTOR SHIELD
26	212711	311104	Harness Clip
27	Y311426	3400029	Nut, Adapter Plate
28	Y015627		Screw- Hex
29	Y052734		Nut, Carrage Bolts And Bracket
30	Y052785		Nut, Brace To Damper
31	Y053241		Set Screw, Motor Pulley
32	054863	Not Available	LOCK WASHER
33	Y055978		Rubber Adhesive, 2 Oz Tube
34	Y056016		Center Seal Grease

