


Maytag LA310 06 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag LA310 Washer Parts Parts Diagram 06 - TOP COVER, CONSOLE & LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205997			Non-Bleach Conversion Kit
2	Y201808			Converter
3	204445			Screw And Fastener Assembly
4	204968			Plunger And Bracket Assembly--W
5	205056	204590		Cord, Power
6	205415	279347		Switch-Lid
8	205537L			Top Cover-Almond---NA
10	205538L		Not Available	TOP COVER-ALMOND
12	205635L		Not Available	CONSOLE (ALM)
14	205915		Not Available	SUDS SAVE HARNESS
15	210186	3370225		Screw
16	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
17	211500			Washer, Bracket To Top Cover
18	211726			Hinge, Ball Lid
19	211737	248562		Terminal

20	211881		Grommet, Cord Part Not Used-Gas Models Only
22	212073L	Not Available	LID-ALMOND
24	212716		Bumper, Lid
25	213718		Plunger, Lid Switch
26	213720		Spring, Lid Switch
27	214436		Gasket
28	214437	215577	Bleach Inlet White
29	214804		Unbalance Lever
30	214805		Pin For Unbalance Lever
31	214813	Not Available	LEVER FOR LID SWITCH
32	214884	213501	Screw, No.6-20 X 1-1/8 Inch
33	214898		Cover For Lid Switch
34	214987		Moisture Barrier For Switch
35	215075		Fastener, Control Panel To Console
36	301548		Clamp, Ground Wire
38	Y312140		Wire Connector
39	Y313559		Screw
40	410635		Fastener
41	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
42	911267		Screw, Pump Cover

