


Maytag LA503 06 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag LA503 Washer Parts Parts Diagram 06 - TOP COVER, CONSOLE & LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y201808			Converter
2	204445			Screw And Fastener Assembly
3	204968			Plunger And Bracket Assembly--W
4	205056	204590		Cord, Power
5	205415	279347		Switch-Lid
6	205538		Not Available	TOP COVER-WHITE
7	205538L		Not Available	TOP COVER-ALMOND
8	205635			Console
9	205635L		Not Available	CONSOLE (ALM)
10	205815		Not Available	MAIN WIRE HARNESS
11	210186	3370225		Screw
12	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
13	211500			Washer, Bracket To Top Cover
14	211726			Hinge, Ball Lid
15	211737	248562		Terminal

16	211881		Grommet, Cord Part Not Used-Gas Models Only
17	212073		LID (WHITE)
18	212073L	Not Available	LID-ALMOND
19	212716		Bumper, Lid
20	213718		Plunger, Lid Switch
21	213720		Spring, Lid Switch
22	214804		Unbalance Lever
23	214805		Pin For Unbalance Lever
24	214813	Not Available	LEVER FOR LID SWITCH
25	214884	213501	Screw, No.6-20 X 1-1/8 Inch
26	214898		Cover For Lid Switch
27	214987		Moisture Barrier For Switch
28	215075		Fastener, Control Panel To Console
29	301548		Clamp, Ground Wire
30	311155		Ground Wire And Clamp
31	Y312140		Wire Connector
32	Y313559		Screw
33	410635		Fastener
34	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
35	911267		Screw, Pump Cover

