



Maytag Residential Maytag LA608S Washer Parts Parts Diagram 04 - CONTROL PARTS
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|------------------------|---------------|---------------------------------|
| 1 | 202770 | 279347 | | Switch-Lid |
| 2 | 203185 | | Not Available | FABRIC SWITCH |
| 3 | 204475 | | | Major Wire Harness |
| 4 | 204483 | | Not Available | TIMER |
| 5 | 204590 | | | Cord, Power |
| 6 | 204663 | | Not Available | TIMER MOTOR 120-60 |
| 7 | 204696 | | | Button Kit For 2-3168 |
| 8 | 204702 | | Not Available | BUTTON KIT FOR 2-3185 |
| 9 | 204968 | | | Plunger And Bracket Assembly--W |
| 10 | 204976 | | | Timer Motor 120-60 RPR |
| 11 | 205160 | | Not Available | TOP COVER-WHITE |
| 12 | 205171 | | Not Available | TIMER DIAL, SUN-GLOW |
| 13 | 205192 | | Not Available | CONTROL PANEL, SUN-GLOW |
| 14 | 205197 | | Not Available | CONTROL PANEL KIT, SUN-GLOW |

| | | | | |
|----|------------------------|---------------------------|---------------|---|
| 15 | 205198 | | Not Available | BRACKET KIT - LEFT HAND |
| 16 | 205199 | | Not Available | BRACKET KIT - RIGHT HAND |
| 17 | 205321 | | | Temperature Control Switch |
| 18 | 205333 | | Not Available | BUTTON KIT FOR 2-5261 |
| 19 | 205336 | | | Water Level Switch |
| 20 | 205338 | | | Button Kit For 2-5336-1 |
| 21 | 205339 | | | Button Kit For 2-5336 |
| 22 | 210186 | 3370225 | | Screw |
| 23 | 210866 | | | Nut, Twin Speed |
| 24 | 211065 | | | Spring, Index Wheel |
| 25 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 26 | 211410 | | | Screw, HeX Head No.8 X 3/8 Inch |
| 27 | 211500 | | | Washer, Bracket To Top Cover |
| 28 | 211605 | | | Bezel, Timer Dial |
| 29 | 211737 | 248562 | | Terminal |
| 30 | 211881 | | | Grommet, Cord Part Not Used-Gas Models Only |
| 31 | 212937 | | Not Available | BARRIER, MOISTURE |
| 32 | 212942 | 22001619 | | Tube, Water Level Switch |
| 33 | 213077 | | Not Available | CAP FOR TIMER KNOB |
| 34 | 213117 | 67006908 | | Screw, Ice Rack |
| 35 | 213322 | | Not Available | MAYTAG DECAL |
| 36 | 213323 | | | Fastener, Exhaust Duct Kit |
| 37 | 213501 | | | Screw, No.6-20 X 1-1/8 Inch |
| 38 | 213718 | | | Plunger, Lid Switch |
| 39 | 213719 | | Not Available | LEVER, UNBALANCE |
| 40 | 213720 | | | Spring, Lid Switch |
| 41 | 213966 | 3400014 | | Screw |
| 42 | 214193 | | Not Available | INSULATOR FOR KINGSTON TIME |
| 43 | 214196 | | Not Available | TIMER KNOB-CLEAR ACRYLIC |
| 44 | 214467 | | Not Available | NUT |
| 45 | 214471 | | Not Available | BACK-UP PLATE |
| 46 | 311155 | | | Ground Wire And Clamp |
| 47 | 303846 | 22003781 | | Screw, Ground Strap |
| 48 | 313122 | | | Screw - Baffle To Tumbler |
| 49 | 910182 | 25-7809 | | Screw, No.6-20 1/2 Flthd Torx |
| 50 | Y313262 | W10116752 | | Retainer- |
| 51 | 410296 | 596669 | | Clamp, Manifold |

the laundry company[®]