Maytag LA882 07 - TRANSMISSION-HELICAL DRIVE



Maytag Residential Maytag LA882 Washer Parts Parts Diagram 07 - TRANSMISSION-HELICAL DRIVE
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200730	22002124		Shaft- Agi
2	Y014839			Collar-Drive Shaft
3	210690			Seal, Rubber
4	200813		Not Available	GEAR CASE COVER ASSEMBLY
5	Y015629			Bolt, Grinding Chamber
6	015639			Dowel Pin
7	210632	22210632		Gasket
8	Y015902			Spring For Agitator
9	Y014827			Washer-Center Shaft
10	210183			Groove Pin
11	201463		Not Available	PITMAN WITH WRIST PIN
12	210670			Segment
13	204967			Gear Kit-Power Fin Agitator
14	203193		Not Available	GEAR HOUSING W/STUDS & TUBE
15	206602	207843		Lip Seal Repair Kit

16	211089			Lug, Stop Pulley
17	211375	681582		Screw
18	211090	22003555		Washer, Stop Lug
19	213044			Shaft, Center
20	210054			Pinion
21	211483	6-2114830		Washer- SP
22	211484			Washer, Lug
23	210315			Pinion
24	211486			Screw, 3/8-16 X 1/2 Inch
25	Y052740	62739		Nut, Lock
26	211487			Groov-Pin
27	205811			Counterweight
28	210172			Lock Washer
30	206478		Not Available	SCREW & WASHER FOR AGITATOR
32	212815		Not Available	DISPENSER CUP
35	203265			Lint Filter-Dispenser
36	203323	22004085		Large Agitator
37	203438	W10172457		Transmison

the laundry company®
the laundry company®
the laundry company®