


Maytag LA9400 04 - CONTROL PANEL

SECTION: CONTROL PANEL
 MODEL: A9400 A9400S A9400W SERIES 01



Issue Date: 7/91

24

Maytag Residential Maytag LA9400 Washer Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212942	22001619		Tube, Water Level Switch
2	214809			Back Up Plate
3	215821		Not Available	CAP, KNOB
4	410296	596669		Clamp, Manifold
6	214897			Pad, Control Panel
7	207215		Not Available	END CAP LH
8	207216		Not Available	END CAP RH
9	214894			Fastener, End Cap
10	207360			Infinite Level Press Switch
11	214872			Palnut, End Cap Note: Nut, Lamp Holder
12	211605			Bezel, Timer Dial
13	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
14	211168	W10139210		Screw, 8-18 X 5/16
15	213117	67006908		Screw, Ice Rack
16	213966	3400014		Screw

17	211065		Spring, Index Wheel
19	207376	22207376	Timer
20	215827		Not Available TIMER DIAL SKIRT
21	215828		Knob, Timer
22	205033	22205033	Motor- Tim
23	207367		Not Available TEMP CONTROL SWITCH - 4 BUTTON
24	207382		Wire Harness

