


# Maytag LAT3600AAE 04 - CONTROL PANEL



Maytag Residential Maytag LAT3600AAE Washer Parts Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001619</a>			Tube, Water Level Switch
2	<a href="#">22001825</a>			Temperature Switch - Rotary
3	<a href="#">22003917</a>			Control Panel Facia
4	22003913	<a href="#">22001663</a>		Knob, Selector Switch
5	<a href="#">211065</a>			Spring, Index Wheel
6	22001662	<a href="#">8534058</a>		Screw
7	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
8	<a href="#">22001776</a>			Inf Level Rot Pressure Switch
9	22002189	<a href="#">22004262</a>		Timer
10	22003914	<a href="#">22001660</a>		Dial Skirt - White
11	<a href="#">22003915</a>			Timer Knob
12	<a href="#">211605</a>			Bezel, Timer Dial
13	<a href="#">22001664</a>			Timer Knob Insert/Cap
14	<a href="#">22001794</a>			Switch, Rotary
15	<a href="#">22002578</a>			Switch, Speed