


# Maytag LAT4000AAW 04 - CONTROL PANEL



Maytag [Residential Maytag LAT4000AAW Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
"	<a href="#">22001132</a>			Plate, Support
"	315483	<a href="#">3370225</a>		Screw
3	22001445		Not Available	CAP, KNOB (BLK)
4	410296	<a href="#">596669</a>		Clamp, Manifold
5	22001568		Not Available	PANEL, CONTROL (BLK)
6	<a href="#">214897</a>			Pad, Control Panel
7	<a href="#">22001267</a>			Knob, Selector Switch
8	22001563	<a href="#">22001288</a>		End Cap, Control Panel
"	22001562	<a href="#">22001290</a>		End Cap, Control Panel
9	<a href="#">214894</a>			Fastener, End Cap
10	<a href="#">214872</a>			Nut, End Cap Note: Nut, Lamp Holder
11	<a href="#">211605</a>			Bezel, Timer Dial
12	311728	<a href="#">210022</a>		Screw, No.8 X 9/16 Ctsk Note:

12	214120	<a href="#">21032</a>		Screw, Inlet Duct
13	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
14	<a href="#">216412</a>			Screw, Bracket To Timer
15	22001569		Not Available	WIRE HARNESS, MAIN
16	22001570		Not Available	TIMER RPR
17	<a href="#">22001571</a>			Bezel, Timer Dial
18	<a href="#">206892</a>			Control Knob
19	<a href="#">211065</a>			Spring, Index Wheel
20	208205		Not Available	SWITCH, PRESSURE
21	22001572		Not Available	MANUAL, USE & CARE (FRENCH)
"	16007386		Not Available	MANUAL, USE & CARE
"	16000327		Not Available	GUIDE, QUICK REF. - MAYTAG

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>