

Maytag LAT5004AGW 06 - TRANSMISSION



Maytag [Residential Maytag LAT5004AGW Washer Parts](#) Parts Diagram 06 - TRANSMISSION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206628			Cover, Transmission
2	207153	6-2097820		Kit- Shaft
3	206713	6-2067130		Gear- Beve
4	215411	12001451		Ctr Shaft W/Collar Andkeeper- Sha
5	215415		Not Available	COLLAR, LOWER
6	206625	6-2097790		Transmison
7	215394			Washer, Bevel Gear
8	211059	6-2301530		Pulley
"	22001441	22002432		Pulley Assembly
9	211483	6-2114830		Washer- SP
10	206602	207843		Lip Seal Repair Kit
11	Y206629			Pin, Collar
12	215401	W10221114		Pinion
13	215395			Plate, Clutch
14	211090	22003555		Washer, Stop Lug
15	211375	681582		Screw

16	215417		Not Available	SCREW, TRANSMISSION COVER
17	210690			Seal, Rubber
18	Y058700	675652		Adhesive
19	215581			Spring, Agitator Shaft
20	211089			Lug, Stop Pulley
21	206685	6-2066850		Yoke
22	206708	6-2097790		Transmison

