

Maytag LAT5914AAE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT5914AAE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	315483	3370225		Screw
"	22001132			Plate, Support
"	204807			Ground Wire, Supp. Plte To Top Cover
3	216250	22001446		Cap, Knob
4	410296	596669		Clamp, Manifold
5	22001227		Not Available	PANEL, CONTROL (WHT)
6	214897			Pad, Control Panel
7	22001215	7730P011-60		Lens, Indicator Light
8	22001291			End Cap, Control Panel
"	22001289		Not Available	END CAP, CTRL. PNL. (LT-WHT)
"	22001564			Cap, End
"	22001565		Not Available	CAP, END (LT-WHT)
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut,

10	214972		Lamp Holder
11	211605		Bezel, Timer Dial
12	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210	Screw, 8-18 X 5/16
14	211168	W10139210	Screw, 8-18 X 5/16
15	216412		Screw, Bracket To Timer
16	903115		Lock Light
17	22001252		Timer RPR
18	22001265		Bezel, Timer Knob
19	22001198	Not Available	KNOB, TIMER (WHT)
20	211065		Spring, Index Wheel
21	208201		Switch, Pressure
22	208281	Not Available	SWITCH, TEMP (4POSITION)
23	22001297		Wire Harness, Main
24	22001268	Not Available	KNOB ASSY. (WHT)
25	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
"	22001098	Not Available	MANUAL, USE & CARE

