


# Maytag LAT5916AAE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT5916AAE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001664</a>			Timer Knob Insert/Cap
3	22001721		Not Available	PANEL, CONTROL (WHT)
4	<a href="#">22001789</a>			Button, Switch
"	<a href="#">22001788</a>			Button, Switch
"	<a href="#">22001783</a>			Switch, Water Temp.
5	<a href="#">211605</a>			Bezel, Timer Dial
6	22001662	<a href="#">8534058</a>		Screw
7	<a href="#">22001757</a>			Wire Harness, Main
"	22002208		Not Available	HARNES, WIRE
8	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
"	<a href="#">22002188</a>			Timer
"	<a href="#">22001693</a>			Timer
9	<a href="#">22001660</a>			Dial Skirt - White
10	<a href="#">22001659</a>			Timer Knob - Grey
11	<a href="#">211065</a>			Spring, Index Wheel

12	22001777	Not Available	SWITCH, WATER LEVEL (INF.-WHT)
13	<a href="#">22001785</a>		Switch, Rinse
"	<a href="#">22001788</a>		Button, Switch
14	22001765	Not Available	MANUAL, USE & CARE
"	22001771	Not Available	MANUAL, USE & CARE (FRENCH)
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

