


Maytag LAT7304DAL 04 - CONTROL PANEL



Maytag [Residential Maytag LAT7304DAL Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	315483	3370225		Screw
"	204807			Ground Wire, Supp. Plte To Top Cover
"	22001132			Plate, Support
3	216193		Not Available	CAP, TIMER KNOB (BLK)
4	410296	596669		Clamp, Manifold
5	22001219			Panel, Control
6	214897			Pad, Control Panel
7	22001267			Knob, Selector Switch
8	22001288			End Cap, Control Panel
"	22001290			End Cap, Control Panel
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder
11	211605			Bezel, Timer Dial
12	311728	210032		Screw, No.8 X 9/16 Ctsk Note:

12	014120	21032		Screw, Inlet Duct
13	211168	W10139210		Screw, 8-18 X 5/16
14	211168	W10139210		Screw, 8-18 X 5/16
15	216412			Screw, Bracket To Timer
16	22001318			Wire Harness, Main
17	22001255			Timer RPR
18	22001264		Not Available	BEZEL, TIMER KNOB (BLK)
19	215828			Knob, Timer
20	211065			Spring, Index Wheel
21	208206			Switch, Pressure
22	208283		Not Available	SWITCH, WATER TEMPERATURE
23	22001105		Not Available	MANUAL, USE & CARE
"	16000327		Not Available	GUIDE, QUICK REF. - MAYTAG

