


Maytag LAT7304EGE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT7304EGE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	315483	3370225		Screw
"	204807			Ground Wire, Supp. Plte To Top Cover
"	22001132			Plate, Support
3	216250	22001446		Cap, Knob
4	410296	596669		Clamp, Manifold
5	22001382		Not Available	PANEL, CONTROL (WHT)
6	214897			Pad, Control Panel
7	22001268		Not Available	KNOB ASSY. (WHT)
8	22001289		Not Available	END CAP, CTRL. PNL. (LT-WHT)
"	22001565		Not Available	CAP, END (LT-WHT)
"	22001291			End Cap, Control Panel
"	22001564			Cap, End
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut,

10	214972		Lamp Holder
11	211605		Bezel, Timer Dial
12	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210	Screw, 8-18 X 5/16
14	211168	W10139210	Screw, 8-18 X 5/16
15	216042	22001627	Screw
16	208743	22001318	Wire Harness, Main
17	22001258		Timer
18	22001265		Bezel, Timer Knob
19	22001198	Not Available	KNOB, TIMER (WHT)
20	211065		Spring, Index Wheel
21	208206		Switch, Pressure
22	208283	Not Available	SWITCH, WATER TEMPERATURE
23	22001105	Not Available	MANUAL, USE & CARE
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

