


Maytag LAT8004AAM 06 - TRANSMISSION



Maytag [Residential Maytag LAT8004AAM Washer Parts](#) Parts Diagram 06 - TRANSMISSION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206628			Cover, Transmission
2	207153	6-2097820		Kit- Shaft
3	206713	6-2067130		Gear- Beve
4	215411	12001451		Ctr Shaft W/Collar Andkeeper- Sha
5	215415		Not Available	COLLAR, LOWER
6	206625	6-2097790		Transmison
7	215394			Washer, Bevel Gear
8	211059	6-2301530		Pulley
9	211483	6-2114830		Washer- SP
10	206602	207843		Lip Seal Repair Kit
11	Y206629			Pin, Collar
12	215401	W10221114		Pinion
13	215395			Plate, Clutch
14	211090	22003555		Washer, Stop Lug
15	211375	681582		Screw
				SCREW, TRANSMISSION

16	215417	Not Available	SCREW, TRANSMISSION COVER
17	210690		Seal, Rubber
18	Y058700	675652	Adhesive
19	215581		Spring, Agitator Shaft
20	211089		Lug, Stop Pulley
21	206685	6-2066850	Yoke
22	206708	6-2097790	Transmison

