

# Maytag LAT8024AAL 04 - CONTROL PANEL



Maytag [Residential Maytag LAT8024AAL Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	315483	<a href="#">3370225</a>		Screw
"	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
"	<a href="#">22001132</a>			Plate, Support
3	216193		Not Available	CAP, TIMER KNOB (BLK)
4	410296	<a href="#">596669</a>		Clamp, Manifold
5	<a href="#">22001223</a>			Panel, Control
6	<a href="#">214897</a>			Pad, Control Panel
7	22001215	<a href="#">7730P011-60</a>		Lens, Indicator Light
8	<a href="#">22001288</a>			End Cap, Control Panel
"	<a href="#">22001290</a>			End Cap, Control Panel
9	<a href="#">214894</a>			Fastener, End Cap
10	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
11	<a href="#">211605</a>			Bezel, Timer Dial
12	311728	<a href="#">210032</a>		Screw, No.8 X 9/16 Ctsk Note:

12	214120	<a href="#">21032</a>		Screw, Inlet Duct
13	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
14	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
15	<a href="#">216412</a>			Screw, Bracket To Timer
16	<a href="#">903115</a>			Lock Light
17	<a href="#">22001255</a>			Timer RPR
18	22001264		Not Available	BEZEL, TIMER KNOB (BLK)
19	<a href="#">215828</a>			Knob, Timer
20	<a href="#">211065</a>			Spring, Index Wheel
21	<a href="#">208206</a>			Switch, Pressure
22	208283		Not Available	SWITCH, WATER TEMPERATURE
23	<a href="#">22001315</a>			Wire Harness, Main
24	<a href="#">22001267</a>			Knob, Selector Switch
25	22001105		Not Available	MANUAL, USE & CARE
"	16000327		Not Available	GUIDE, QUICK REF. - MAYTAG

