


Maytag LAT8608AAL 06 - TOP



Maytag [Residential Maytag LAT8608AAL Washer Parts](#) Parts Diagram 06 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	215075			Fastener, Control Panel To Console
2	205635L		Not Available	CONSOLE (ALM)
3	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	Y313559			Screw
5	211726			Hinge, Ball Lid
6	212073L		Not Available	LID-ALMOND
7	207168	22001682		Switch Assembly, Lid W/4amp Fuse
8	207167			Block, Fuse
9	205415	279347		Switch-Lid
10	207159	489355		Screw, 8 X 1/2
11	211881			Grommet, Cord Part Not Used-Gas Models Only
12	204590			Cord, Power
"	210186	3370225		Screw
13	210186	3370225		Screw

15	214436		Gasket
16	212716		Bumper, Lid
17	204445		Screw And Fastener Assembly
18	207172L		Top Cover Assembly ALM--- NA
19	Y215699	22001678	Bracket, Switch And Fuse
20	207166		Switch, Check
21	22001352		Screw, Check Switch
22	213501		Screw, No.6-20 X 1-1/8 Inch
23	Y311711		Screw, Fuse Block
24	301548		Clamp, Ground Wire
25	311155		Ground Wire And Clamp
26	215700	Not Available	LID SWITCH PLUNGER
27	215704		Lever, Unbalance
28	213720		Spring, Lid Switch
29	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
30	211500		Washer, Bracket To Top Cover
31	214279	204968	Plunger And Bracket Assembly--W

