


Maytag LAT8608AAL 07 - TRANSMISSION-ORBITAL



14

Maytag Residential Maytag LAT8608AAL Washer Parts Parts Diagram 07 - TRANSMISSION-ORBITAL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206707	6-2097750		Trans Dee
2	207153	6-2097820		Kit- Shaft
3	206713	6-2067130		Gear- Beve
4	215581			Spring, Agitator Shaft
5	206685	6-2066850		Yoke
6	206628			Cover, Transmission
7	215417		Not Available	SCREW, TRANSMISSION COVER
8	215415		Not Available	COLLAR, LOWER
9	215401	W10221114		Pinion
10	215395			Plate, Clutch
11	211483	6-2114830		Washer- SP
12	Y206629			Pin, Collar
13	215733			Dispensing Cup
14	207426			Lint Filter Deep
15	207228			Agitator W/Lock Screw
				SCREW & WASHER FOR

16	206478	Not Available	SCREW & WASHER FOR AGITATOR
17	215410	12001450	Ctr Shaft W/Collar Andkeeper-Dp
18	211059	6-2301530	Pulley
19	211089		Lug, Stop Pulley
20	211375	681582	Screw
21	211090	22003555	Washer, Stop Lug
22	206602	207843	Lip Seal Repair Kit
23	215394		Washer, Bevel Gear
25	Y058700	675652	Adhesive
26	210690		Seal, Rubber
27	038228	20000021	Lip Seal Tool Kit

Howes
the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]