


# Maytag LAT8616AAM 04 - CONTROL PANEL



Maytag [Residential Maytag LAT8616AAM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001665</a>			Insert, Timer Knob
3	22001746		Not Available	PANEL, CONTROL (ALM)
4	22001791	<a href="#">22003875</a>		Button- SW
"	22001790	<a href="#">22003876</a>		Button- SW
"	<a href="#">22001784</a>			Switch, Water Temp.
5	<a href="#">211605</a>			Bezel, Timer Dial
6	22001662	<a href="#">8534058</a>		Screw
7	<a href="#">22001757</a>			Wire Harness, Main
"	22002208		Not Available	HARNES, WIRE
8	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
"	<a href="#">22002188</a>			Timer
"	<a href="#">22001693</a>			Timer
9	22001668		Not Available	BEZEL, TIMER KNOB (ALM)
10	<a href="#">22001659</a>			Timer Knob - Grey
11	<a href="#">211065</a>			Spring, Index Wheel

12	22001780		Not Available	SWITCH, WATER LEVEL (4 P.-ALM)
13	<a href="#">22001786</a>			Switch, Rinse
"	22001790	<a href="#">22003876</a>		Button- SW
14	22001765		Not Available	MANUAL, USE & CARE
"	22001771		Not Available	MANUAL, USE & CARE (FRENCH)
"	16000327		Not Available	GUIDE, QUICK REF. - MAYTAG

