


Maytag LAT8616AAM 05 - TOP



Maytag [Residential Maytag LAT8616AAM Washer Parts](#) Parts Diagram 05 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211726			Hinge, Ball Lid
2	22001298			Cap, Top Cover
"	207159	489355		Screw, 8 X 1/2
3	207167			Block, Fuse
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
4	22002135			Bracket, Unbalance
"	22001645		Not Available	BRACKET, UNBALANCE---NA
5	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
"	207166			Switch, Check
6	22001671			Console ---NA
7	213720			Spring, Lid Switch
8	211881			Grommet, Cord Part Not Used-Gas Models Only
9	22001662	8534058		Screw
"	216423	3370225		Screw

"	22001814		Back Panel, Console
10	22001673	22001682	Switch Assembly, Lid W/4amp Fuse
"	W10124350		Not Available
11	22001672		Lever, Unbalance
"	22001968		Lever, Unbalance
12	Y705026	3370225	Screw
"	22001654		Wire, Ground
13	22001675		Not Available
"	22001677		Not Available
14	212716		LID W/LEGEND (ALM)
15	22001967	12001908	LID W/LEGEND (CANADA-ALM)--NA
"	205415	279347	Bumper, Lid
16	216255		Switch-Lid
17	211500		Switch-Lid
18	W10124350		Plunger, Lid Switch
"	22001678		Washer, Bracket To Top Cover
19	208194	22003062	NOT REQUIRED PART OR SEE NOTE
20	22001402	214354	Bracket, Switch And Fuse
21	207159	489355	Cord, Power
22	Y705026	3370225	Screw, Top Cover To Cabnt.
23	216423	3370225	Screw, 8 X 1/2
24	213501		Screw
25	Y311711		Screw
26	216423	3370225	Screw, No.6-20 X 1-1/8 Inch
27	22001600	25-7809	Screw, Fuse Block
28	22001352		Screw
29	22001782	22002146	Screw, No.6-20 1/2 Flthd Torx
30	22001681		Screw, Check Switch
"	22001969		Cover Assembly, Top
31	W10124350		Not Available
"	22001682		Unbalance Lever Assembly
32	215374		Unbalance Lever Assembly
33	22001008		NOT REQUIRED PART OR SEE NOTE
			Switch Assembly, Lid W/4amp Fuse
			GASKET FOR BLEACH CUP
			Cup, Bleach

